

ROKINON **F**[®]



14mm F2.8 Auto Focus Canon RF Mount Instruction Manual

This Full Frame prime lens is specifically designed to provide optimal quality ultra wide-angle still images and video with Canon R series cameras.

Advantages

- Its 14mm focal length is well suited for landscapes, interior, architecture, and astrophotography.
- Its ultra-wide view, performance and image quality competes with the best in its class.
- UMC anti-reflective coatings, one High Refractive Index, two ED, and three high precision Aspherical elements combine to minimize aberrations and distortion.
- Autofocusing utilizes a STM (Stepless Motor) for quiet, smooth, and precise focus that is especially important when recording video.

• The IF (Internal Focus) design prevents both changes in length and front element rotation.

• Its size, shape and grips have been ergonomically designed for enhanced stability and comfortable use.

• The refined metal chassis offers excellent durability and is weather sealed to help protect against dust and moisture.

• It is equipped with a rear filter holder which is designed to allow convenient use of polyester or polycarbonate gel filters without vignetting.

Cautions

To maintain your safety and prevent damage to the lens, please fully familiarize yourself with the following:

• Do not look directly at the sun through the lens as it may seriously impair your vision.

• Do not to apply excessive force when attaching the lens to the camera as it may cause damage to the lens or your camera.

• The lens is a precision optical product, so dropping or excessive impact may cause product failure.

• Attach or detach the lens only while the camera is turned off.

• Protect the lens from water, high humidity and excessive heat.

• Always store the lens with the lens cap on in a dry and well ventilated location out of direct sunlight. Direct sunlight passing through the lens could become concentrated enough to cause a fire.

• Avoid subjecting the lens to drastic temperature changes such as moving from a very cold outdoors location to a warm indoors location. This can cause moisture in the air to condense inside or on the outside of the lens and lead to failure or mold production. Before taking the lens indoors from a cold outdoors location, put the lens in a plastic bag or sealed camera bag and remove it only when the lens has warmed up to room temperature.

CAUTION

! When mounting the lens make sure that it clicks in place otherwise it may detach and cause damage or injury.



! Do not apply excessive force on the lens when it is attached to the camera. It may damage the lens and camera mount.



! Ensure that the lens is operating properly by testing it on your camera before shooting an important event.



! Do not modify or try to repair the lens as this will void the warranty.



! Do not leave the lens in direct sunlight as this could cause a fire.



! Do not look directly at the sun through a camera with a lens attached as it may damage your eyesight.



Cleaning

• It is extremely important before cleaning to dust off the lens surface using a lens blower or a soft brush to remove any foreign particles or grit that could scratch the lens.

• Using a clean microfiber lens cloth, gently wipe the lens in a circular motion from the center outwards towards the edges of the glass.

• If stubborn spots remain, put only one or two small drops of ethanol or reputable lens cleaner on the microfiber cloth and repeat the circular cleaning process. **DO NOT USE AN ORGANIC SOLVENT SUCH AS PAINT THINNER, ALCOHOL, OR BENZENE.**

Focusing

Canon R series cameras offer various methods of focusing. For detailed information regarding the available focus mode settings for your particular model, refer to the instruction manual of your camera.

• Set the AF/MF switch to "AF" for auto focus operation.

• For manual focus operation set the switch to "M". Manual Focus allows you instead of the camera to adjust the focus by rotating the manual focus ring on the lens. Manual focus is effective when auto focus does not work well.

Included Components

- Front Lens Cap
- Rear Lens Cap
- Warranty Card
- Soft Lens Pouch
- Instruction Manual

Parts



- ① Built-In Hood
- ② Manual Focus Ring
- ③ Lens Mount
- ④ AF / Manual Switch
- ⑤ White Index Mark
- ⑥ Contacts
- ⑦ Gel Filter Holder

Attaching the Lens

- Remove the rear lens cap and the camera body cap.
- Align the white index mark on the lens barrel with the red index mark on the lens mount of the camera.
- Do not press the lens release button on the camera when mounting the lens.
- Insert the lens into the camera mount and rotate it clockwise until it “clicks” and locks in place. Do not insert the lens at an angle.
- Remove the front lens cap when you are ready to shoot.

Detaching the Lens

- Attach the front lens cap.
- While holding down the lens release button on the camera body, rotate the lens counterclockwise until it stops and separate the lens from the body.
- Attach the rear lens cap.

Product Specifications

Model	IO14AF-RF
Aperture range	F2.8 ~ 22
Mount	Canon RF
Angle of view (Full frame / APS-C)	113.9° / 89.8°
Optical construction	14 elements in 10 groups (Including 2 ED, 3 Aspherical, and 1 HRI)
Minimum focusing distance	7.9" (0.20m)
Maximum magnification	0.12X
Rear filter holder	Yes
Weather sealed	Yes
Number of aperture blades	7
Maximum diameter x length	3.39 x 3.75" (86 x 95.3mm)
Weight	17.1 oz (484g)

- The minimum focus is the distance from the image sensor to the object.

Contacts

Elite Brands Inc.
Rokinon Division
New York, NY 10005

Toll Free: 800.441.1100
Phone: 212.947.7100
support@rokinon.com

rokinon.com
facebook.com/rokinonlenses
instagram.com/rokinon

ROKINON® is a registered trademark of Elite Brands Inc.
©2019, Elite Brands Inc., New York, NY 10005

The product specifications and design are subject to change without notice.

Notes